### Addendum

HC908JL3AD/D Rev. 4, 10/2003

Addendum to MC68HC908JL3 Technical Data



This addendum provides changes and additional information to:

MC68HC908JL3 Technical Data

(Freesca; e document number MC68HC908JL3/H Rev. 1.0)

#### **NOTE:**

To provide the most up-to-date information, the revision of our documents on the World Wide Web will be the most current. Your printed copy may be an earlier revision. To verify you have the latest information available, refer to:

http://freescale.com

### Page 43

### **4.7 FLASH Program Operation** — remove the note:

"In order to avoid program disturbs, the row must be erased before any byte on that row is programmed."

### 48-Pin LQFP MC68H(R)C908JL3

The 48-pin LQFP package is available for the MC68HC908JL3 and MC68HRC908JL3. The pin assignment and mechanical drawing are shown in **Figure 1** and **Figure 2** respectively.

#### **Order Numbers:**

MC order number	Oscillator type	FLASH memory	Operating Voltage	Package
MC68HC908JL3CFA	Crystal	4096 Bytes	5V ±10% 3V ±10%	48-pin LQFP
MC68HRC908JL3CFA	RC			

Notes:


 $C = -40 \, ^{\circ}C$  to  $+85 \, ^{\circ}C$ 

FA = Plastic Low Quad Flat Pack (LQFP)

© Freescale Semiconductor, Inc., 2004. All rights reserved.



## 48-Pin LQFP Pin Assignment



NC: No connection

Figure 1. 48-Pin LQFP Pin Assignment

HC908JL3AD/D 48-Pin LQFP MC68H(R)C908JL3

48-Pin LQFP Mechanical Specification




Figure 2. 48-Pin Plastic Low Quad Flat Pack (LQFP) (Case #932)

# Freescale Semiconductor, Inc.

Home Page:

www.freescale.com

email:

support@freescale.com

**USA/Europe or Locations Not Listed:** 

Freescale Semiconductor Technical Information Center, CH370 1300 N. Alma School Road Chandler, Arizona 85224 (800) 521-6274 480-768-2130

support@freescale.com

Europe, Middle East, and Africa:

Freescale Halbleiter Deutschland GmbH

**Technical Information Center** 

Schatzbogen 7

81829 Muenchen, Germany

+44 1296 380 456 (English)

+46 8 52200080 (English)

+49 89 92103 559 (German)

+33 1 69 35 48 48 (French)

support@freescale.com

Japan:

Freescale Semiconductor Japan Ltd.

Headquarters

ARCO Tower 15F

1-8-1, Shimo-Meguro, Meguro-ku

Tokyo 153-0064, Japan

0120 191014

+81 2666 8080

support.japan@freescale.com

Asia/Pacific:

Freescale Semiconductor Hong Kong Ltd.

Technical Information Center

2 Dai King Street

Tai Po Industrial Estate,

Tai Po, N.T., Hong Kong

+800 2666 8080

support.asia@freescale.com

For Literature Requests Only:

Freescale Semiconductor Literature Distribution Center

P.O. Box 5405

Denver, Colorado 80217

(800) 441-2447

303-675-2140

Fax: 303-675-2150 LDCForFreescaleSemiconductor

@hibbertgroup.com

RoHS-compliant and/or Pb- free versions of Freescale products have the functionality and electrical characteristics of their non-RoHS-compliant and/or non-Pb- free counterparts. For further information, see http://www.freescale.com or contact your Freescale sales representative.

For information on Freescale.s Environmental Products program, go to http://www.freescale.com/epp.

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document. Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters which may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals" must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

